

Mini WebCam

Users Manual

© 2002 Sakar International, Inc. All rights reserved. iConcepts, the iConcepts logo, and product names referred to herein are the registered trademarks of iConcepts. Windows and the Windows logo are registered trademarks of Microsoft Corporation. All other trademarks are the property of their respective owners.

Introduction

Thank you for purchasing the Mini WebCam. Simply plug the Note Mini WebCam into your USB port to make your world come alive. For use with both your Notebook and Desktop PC.. Broadcast your Party or chat with video or show you LIVE!

Package Contents:

- iConceptsTM Notebook Cam
- · User's Manual
- · Warranty Card
- · CD ROM Software

System Requirements:

- → Windows®98,2000,ME or XP
- Pentium®III400, Celeron®AMD Athlon®processor.
- or higher (Pentium®III400,Celeron®AMD Athlon®processor,
- AGP video card recommended)
- 64MB RAM
- 100MB free hard drive space
- · CD-ROM Driver
- · Available USB Port
- · 16-bit color display adapter

Software Installation


Please place the CD into the CD-ROM driver and the software will automatically run the installation wizard; please follow the directions of the installation wizard.

Note: If the auto run function in your computer is not functioning, you must manually install the software according to the following steps:

- 1. Place the CD into the CD-ROM driver.
- 2. Click with right key on the start Menu, and then run.
- 3. Enter D:\Setup (If D is your CD-ROM driver letter) in the running dialog box;
- Follow the directions of the installation wizard.

AMCAP User Guide

Start: Double click icon "AMCAP" on the table or select program library >ICM 532>AMCAP, there will show out the PC Camera menu



• File Menu-:

Set Capture File: Pre-set the name of the file which you are going to capture Allocate file Space: Set the file size of the capture. Please note that if the file size of the captured file exceeds the pre-set file, the balance will be cut.

Save captured Video As: Set the saved captured video file name

Exit: Exit the AMCAP

• Devices Menu:

Video Device: It will show all video devices you installed. It will show ICM532A for Mini WebCam Sound Device: It will show all audio devices you installed

• Options Menu:

Preview: Default is active.

Audio Format: This is an audio format setting.

Video Capture Filter: This is a video capture setting. It included brightness and contrast

setting. Default setting is 50

Video Capture Pin: This is resolution setting of capture file. You may select for CIF

mode (352*288) pixels or QCIF mode (160x120) pixels

Audio Capture Filter: This is an audio setting

• Capture Menu:

Start Capture: Select to start capturing the video Stop Capture: Select to stop capturing the video

Capture Audio: The default is active Master Stream: None/Audio/Video

Set Frame Rate: To set the frame rate per second


Set Time Limit: To set the capture Video time limit, the capture video taken Help:-It will show the driver version of **Mini WebCam**.

• Play the capture file:

To play the saved capture file please double click the file from the saved directory, it will auto play the AVI player.

VIDCAP User Guide

Start: Select program library>ICM532>VIDCAP



• File Menu:

Load Palette: Load some palette which you want to use

Set Capture File: Pre-set file name Allocate File Space: Set file size

Save Captured file As: Set the saved Captured Video file name

Save Palette: Save Palette

Save Single Frame: Only capture one frame Edit Captured Video: To edit the captured Video

Exit: Exit the VIDCAP Mode

• Edit Menu:

Copy: Copy a file

Preference: Adjust image properties

• Options Menu:

Audio Format: This is an audio format setting Video Format: This is a video format setting

Video Source: This is a video capture setting. It includes brightness and contrast

setting. The default is 50 HZ

Video Display: Default is active

Compression: To set compressed mode for the video

Preview: Default is active

• Capture Menu:

Single Frame: Only capture one frame Frame: To capture many frames

Video: To set frame rate

Video Conference User Guide

Start: Run the videoconference software Microsoft Net MeetingTM on your computer





• Calling Menu:

New: Add a new address you want to call Manage: You preside the meeting personally

Content: Meeting Contents

Log In Directory: Write In Directory

Directory: Add Directory

No Interrupting: no interrupting

Automatically Accept Called: Accept others' calling

Speed Dial: To establish Speed Dialing

Hang off: Cancel Exit: Exit the calling

· View Menu:

State Bar: To Display State Bar

Dial Board: To Display Dialing keyboard Parent Panels: To display double panels

My Video: To Display Live

Cut: To Cut unnecessary information

Only detect document: Only detect document

Above: To Display above layer

· Tool Menu:

Video: To Hold Video Conference
Adjust: To Adjust Image Property
Sharing: To Join in the Video Conference

Talk: To Chat with others
White: Electronic White Board

Send File: Transfer file

Remote Desk Sharing: Share with others via internet

Option: Other Options

· Help Menu:

Help Content: To Read Help contents Read Me: Information about Netmeeting Microsoft On The Web: To Visit Microsoft web

Support Online: To Get Support Online

About NetMeeting: To Show the Version of NetMeeting

SPECIFICATION:

Product Type: Mini WebCam

Electronic Coupling Element: CMOS Sensor 100K pixels

Image Resolution: 352*288 pixel

File Format: AVI Frame Rate: 12fps Lens: f=3.6;F=2.4;54°

Image Process: Automatic White balance

Transmission Interface: USB Interface Revision 1.1

Working Temperature:0-40°C

Operation System: Windows® 98/Me/2000/XP

For other questions or hints, visit http://www.pccrisis.com/prdsupic.htm